

Channel Wall Mirror Installation Instructions (BCCWM)

- 1. Determine top of unit by locating the removable screws that hold top channel to mirror frame. Top channel can be removed now or after frame is attached to wall. See Figure 1
- 2. Locate desired position of mirror on wall. Attach mirror frame to wall into studs, pre-drill and *countersink* screws. A minimum of two screws through top 6" frame rail and two through bottom 6" frame rail is recommended, more may be installed depending on overall mirror size. See Figure 2
- 3. Remove top channel from mirror frame if still attached. Insert mirror into bottom channel groove. Reattach top channel. Note: Mirror is not shown in picture. See Figure 3

Figure 1



Figure 2



Figure 3

