



# Wall Hung Cabinet Installation Instructions

(BCWHCxx, BCWHDBxx, BCWHDBPOxx)

1. Locate desired position of cabinet on wall to attach the metal wall rail. Note position of metal cabinet hangers on cabinet for proper position of metal wall rail.
2. Attach the metal wall rail to studs with pan head screws. Recommend securing to as many studs as possible. There is an "A" marked on the metal rail in intervals of 4" to help locate studs in the wall – four A's equal 16". (Do not attach only to sheetrock/drywall) See Figure 1
3. Slide cabinet hangers (one attached to each end of cabinet) over metal wall rail. Screws on cabinet hanger inside cabinet allow for close-fitting wall adjustment and leveling adjustment. See Figure 2
4. After cabinet is hung and leveled, attach installation screws through back into studs to secure to wall. See Figure 3

Figure 1



Figure 2



Figure 3

